

ACCURA

ORB ELECTRONIC KITCHEN SCALE






ACC5043ASS OPERATING W

Thank you for choosing the Accura Orb Electronic Kitchen Scale. To ensure proper operation and to maintain the lifespan and the accuracy of the scale, please read these instructions before use.

KEY FEATURES

- Capacity: 5kg/11lbs/169 fl oz
- Graduation: 1g/0.1oz/0.03 fl oz
- Units: g, lb, oz, ml, fl oz
- Tempered glass platform
- Tare function/add and weigh
- 1x CR2032 lithium battery included

OPERATION INSTRUCTIONS

- Place scale on a firm, flat surface to use. A kitchen bench is ideal.
- To switch between units, press the UNIT button.
- If using a bowl place onto the scale before switching on.
- Press the  / TARE button to turn on.
- Press the  / TARE button to tare the scale / return the weight to zero.
- To change unit of measure between metric and imperial, hold the "UNIT" button for approx. 4 seconds.
- To change between units of measure press the "UNIT" button.
- For the most accurate weight ensure the item is in the middle of the platform.
- If measuring multiple ingredients in the one bowl press the  / TARE button between each new ingredient.
- If the screen reads "Err" the scale is overloaded, please remove the weight and reset the scale to zero by pressing the  / TARE button.
- If the screen reads "Lo" the battery will require replacing.
- Turn the scale off by holding the  / TARE button.

CARE

- Wipe the surface of the scale with a damp cloth and dry before and after each use.
- Do not immerse in water and do not use any detergents
- Do not leave the scale in a damp or steamy environment
- The scale is for domestic use only and is not legal for trade.
- If the scale is not being used for a long period, please remove the batteries.



- **Warning — keep batteries out of the reach of children.**
- This product contains a button battery.
- Swallowing may lead to serious injury in as little as 2 hours or death, due to chemical burns and potential perforation of the oesophagus.
- If you suspect your child has swallowed or inserted a button battery immediately call:
- **Australia**
24-hour Poisons Information Centre on 131 126
- **New Zealand**
24-hour National Poison Centre on 0800 764 766
- Examine devices and make sure the battery compartment is correctly secured. Do not use if compartment is not secure.
- Dispose of used button batteries immediately and safely. Flat batteries can still be dangerous.
- Tell others about the risk associated with button batteries and how to keep their children safe.
- Visit www.thebatterycontrolled.com.au for more information on battery safety.

CONTACT

Albi

P: +61 (03) 9474 1300

E: albi@albi.com.au

www.albi.com.au