

DAVIS & WADDELL

DES0153 Electric Personal Blender Operating Manual

Thank you for choosing the Davis & Waddell Electric Personal Blender. To ensure proper operation and to maintain the lifespan of your appliance, please read these instructions carefully before use.

1. Key Features

- Create smoothies and juices to enjoy on the go or at home
- 2 x 570ml tritan bottles come with sip and seal lids
- 4 blade design crushes ice with ease
- Quiet 300w motor
- 12 month warranty

2. Important Safety Instructions

When using electric appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- Read all the instructions before operating this appliance.
- Children should be supervised to ensure they do not play with the appliance.
- Do not immerse the motor base, plug or cord in water or any other liquid
- Unplug the appliance when not in use or being cleaned.
- Pull out from the power outlet by grasping the plug, never by the cord.
- Always check the integrity of the cord before use, if the cord or plug is damaged do not use.
- This appliance should be kept away from hot gas, heated oven, electric burner or any hot surface.
- The appliance should always be used on a hard stable surface, such as table or benchtop.
- The appliance should always be operated with the travel bottle securely in place.
- Keep hands and utensils out of the bottle while blending to reduce the risk of severe injury. A scraper may be used only when the blender is not operational.
- Do not fill the travel bottle above the max capacity; when blending hot liquids only fill half way.
- Do not operate the blender when empty.
- Do not store food in the travel bottle.
- Do not remove the travel bottle from the motor base or replace it until the motor has stopped.
- Do not use if the travel bottle is cracked or chipped.
- Take care when cleaning the blender as the blades are sharp.
- This appliance is intended for household use, not commercial use.
- Store these instructions for future reference.

3. Operation Instructions

- Clean the appliance thoroughly before use.
- Do not fill the travel bottle above the max indicator, or ½ capacity when blending hot liquids.
- Add your ingredients to the travel bottle.
- Fasten the blade base to the travel bottle. CAUTION: Take care when handling blades, do not touch blades directly.
- Turn the bottle upside down and place on top of the motor unit. Twist to lock into place.
- Press down on the pulse button to begin blending.
- Do not remove the travel bottle from the motor base until the motor has stopped.
- Clean and allow the base unit to cool before storing.

NOTE: Do not attempt to use any utensils inside the blender cup unless the blades have fully stopped moving.

4. To Clean

- Switch off the blender and unplug.
- Whenever possible, rinse parts immediately after processing to make cleanup easier.
- Use extreme care when handling blades. Do not touch the blades with your fingers.
- Disassemble the blender. Wash the travel bottle with the blades and lid in warm, soapy water. Rinse and dry thoroughly. Never use rough scouring pads or abrasive cleaners as the surface may be damaged.
- Travel bottle and lids are dishwasher safe.
- Wipe the motor unit with a damp cloth; do not use detergent or abrasives as these may scratch the surface.
- Do not fill the travel bottle with boiling water or place any of the parts in boiling water.
- Do not allow the blades to soak in water for long periods of time.
- Dry thoroughly.
- Properly reassemble all parts before storing.
- Never immerse the base unit, electrical cord or plug in water.
- Allow to dry thoroughly before storing.

5. Guarantee

If after following these instructions the Electric Personal Blender does not work, there may be a manufacturing problem. If this is the case, Albi guarantees this product for 1 year from the date of purchase. The full details of this guarantee can be found at www.albi.com.au or by calling (03) 9474 1300. In the event of such a problem you should return it to the place from which you bought it, WITH PROOF OF PURCHASE, in the form of a valid receipt. Damage through misuse will nullify this guarantee.

For any other advice please contact:

Customer Care
Albi
87 Chifley Drive,
Preston Vic 3072

Phone: 03 9474 1300
Email: albi@albi.com.au